## **Attaching the Ferrite Core**


Copyright ©2006 ROLAND CORPORATION
All rights reserved. No part of this publication may be reproduced in any form
without the written permission of ROLAND CORPORATION.

## You must attach the ferrite core before using the USB cable.

If you use a USB cable to connect the MC-808 to your computer, you must attach the included ferrite core.

This is for the purpose of preventing electromagnetic interference; do not remove it.

- \* Use only the ferrite core that are supplied with the MC-808.
  - **1.** Attach the ferrite core to the USB cable.
    - \* Make sure to attach it near the plug on the end that connects to the MC-808.



**2.** Press the halves together until they click shut.



\* If the USB cable is thin, the attached ferrite core may slide along the cable. If so, use a band or adhesive tape to fasten the ferrite core in place. One such band is included.



- \* Be careful not to pinch your fingers when attaching the ferrite core.
- \* Do not damage the cable by pinching it excessively with the ferrite core.

## フェライト・コアの取り付け方

@ 2006 ローランド株式会社


本書の一部、もしくは全部を無断で複写・転載することを禁じます。

## USB ケーブルをお使いになる前に、必ずフェライト・コアを取り付けてください。

USB ケーブルを使って、MC-808 とコンピューターを接続する場合には、付属のフェライト・コアを取り付けてください。

コンピューターとの電磁的な干渉を防止するためですので、取り外さないでください。

- ※ フェライト・コアは必ず付属のものをお使いください。
  - 1. フェライト・コアを USB ケーブルに取り付けます。
  - ※ 必ず、MC-808側のプラグの間近に取り付けてください。



**2.** カチッと音がするまで押し込みます。



※ お使いの USB ケーブルが細い場合、取り付けたフェライト・コアが 緩んで動いてしまうことがあります。このような場合は、バンドやテープなどで固 定してください。固定用のバンドは 1 本付属しています。



- ※ フェライト・コアを取り付けるとき、指などを挟まないようにご注意ください。
- ※ フェライト・コアを閉めるとき、ケーブルを無理に挟まないでください。